

RHINO-RACK®

Toyota Hilux Gen 8 & 9 Non-Invasive Backbone


RNITHB1

Important:

1. Check the Rhino-Rack website to ensure you have the latest issue of these instructions.
2. Please refer to your fitting instruction to ensure that the product is installed correctly.
3. Check the contents of kit before commencing fitment and report any discrepancies.
4. Place these instructions in the vehicle's glove box after installation is complete.
5. These instructions must be followed for warranty to be upheld.

Fit Time: 1 hour

NOTE: 62100/65100 Pioneer Platform **must be unpacked/assembled** before commencing these Fitting Instructions



Australian Patent
2023370513

USA
(19/124,712)

Patent Pending NZ
(819921)


For details see rhinorack.com/patents

RHINORACK.COM

Doc. No: 520-RFI-00169

Issue No: 1

Issue Date: 20/04/2026



Distribute loads evenly and laterally/longitudinally as low as possible over the span.

Avoid point loads concentrated at the front or rear.


Without a load:



Do not exceed a maximum speed of
130 km/h (80 mph)



130 KM/H
80 MPH




With a load:




Do not exceed a maximum speed of
100 km/h (62MPH)





100 KM/H
62 MPH



Use extreme caution transporting wind-resistant loads when cornering or braking.






Off-road conditions can be more rigorous. Use extreme caution on paths without a sealed surface like tar or bitumen.




Surfboards / Kayaks with overhangs greater than **600mm / 23 5/8in** must be tied to the bonnet.





Loads must be tied down to Cross Bars, not around backbone






Use only non-stretch fastening ropes or straps to attach cargo to roof racks




Ensure sunroof will not collide with roof rack system.





[Youtube.com/Rhinorackaustralia](https://www.youtube.com/Rhinorackaustralia)



If tying down open awnings, attach any tension strap or guy ropes to the platform or an anchor on the platform.
DO NOT tie off to the backbone blades.



DO NOT tie down or transport loads attached to the backbone blades. All cargo must be transported on and tied down to the platform.



Always use two hands at equal distance to lift the Backbone to avoid bending.


Carrying Capacity

Check the website and the vehicle owners hand book for your vehicle manufacturer's maximum carrying capacity. Load must be evenly distributed over the system.



Cargo Load Limit

Total permissible weight allowed on top, and attached to the rack whilst the vehicle is in motion.



System Weight

Total weight of the rack system. (e.g. Crossbars, Backbone, Platform)



Max System Load Capacity

Please ensure you use the vehicle manufacturer's maximum roof allowance if it is lower than the figure listed in the fitting chart/supplement.




Vehicle Manufacturer's Load Limit


Total permissible weight attached to the rack. This is inclusive of the weight of the rack system.

System has been rigorously vibration and crash tested, and is suitable for full cargo carrying capacity in both on and off-road conditions.

Pioneer 6 Tradie / 65100



Pioneer 6 / 62100



In Service Maintenance Checks

- All bolt connections should be checked after driving a short distance when you first install your roof racks.
- All bolted connections should be checked again at regular intervals (weekly is recommended, depending on road conditions, usage, loads and distances travelled).
- All bolted connections should be checked each time they are re-fitted.
- Off-road conditions are more rigorous. Check all bolted connections and your load more regularly.
- Ensure that your vehicle manufacturer's GVM, and gross axle weights are not exceeded (refer to vehicle owner's manual).

Torque Settings:

Unless stated otherwise in these instructions, all fasteners should be set to the following torque settings:




Note for Dealers and Fitters

It is your responsibility to ensure these fitting instructions are given to the end user or client. These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.

Warranty


We love creating our products for you and hope you love using them too. For complete peace of mind, register your product at www.rhinorack.com/warranty. This way, we can quickly help you with any future approved fitment warranty claims.

And remember – never to forget to **Make Space For Adventure!**




Parts


T-Bolt

A x6



LEFT Blade

B x1



RIGHT Blade

C x1


M8 Nyloc Nut

D x6



Pin

E x4



E-Clip

F x4



Pivot Base Plate

G x4



M6 x 12mm Torx Pan Head Screw

H x4



T30 Torx Key

I x1



Base

J x4



REAR Right Pad M700

K x1



REAR Left Pad M699

L x1



FRONT Right Pad M698

M x1



FRONT Left Pad M697

N x1



M8 Leg Bolt

O x8



FRONT Left Clamp

P x1



REAR Left Clamp

Q x1



FRONT Right Clamp

R x1


REAR Right Clamp

S x1



Clamp Clip

T x8


Clamp Cover

U x4



Torque tool

V x1


Key

W x2


Measuring strip

X x4


Instructions

Y x1


TOOLS REQUIRED:

T1 - Tape Measure

T2 - Torque Wrench & 13mm Socket

T3 - 1/2" Spanner

T4 - Scissors

This fit is **ONLY APPLICABLE** with Pioneer **62100** and **65100**. The platform must be **UNPACKED/ASSEMBLED** before commencing these steps.

1

Fairings indicate **FRONT**

2

The underbars on the Pioneer need to be adjusted using the following measurements.

FRONT - **REAR**

Bar **A** -40mm Bar **B** -0.5mm Bar **C** +35mm

3

Cut the measurings strips **X** to the correct size.


FRONT

T4 x2
45mm

REAR



T4 x2
49mm

4a



4b



At the front of the Platform ensure that the **45mm** measuring strips are inserted into the underbar and pushed all the way out towards the edge of the platform



Repeat this step on the opposite side


4c

At the rear of the Platform ensure that the **49mm** measuring strips are inserted into the underbar and pushed all the way out towards the edge of the platform




Repeat this step on the opposite side


5






6a




6b Align the inside edge of both **B** & **C** touch but dont overlap the measuring strips in the channel.







NOTE:

The feet assemblies come pre-assembled for packing purposes. Separate the parts, then proceed with the following steps.




10




SCREW HOLES FACE CENTRE


11




I + **V**




Torque till **I** clicks



12




13



NOTE:


If required, remove Base **J** and the pad from the leg. Ensure Base **J** is fully seated against the pad, then reinstall the base in the correct orientation

14




15a


Place the assembly onto the roof of the vehicle in the correct orientation





15b




16




17 Clamp




18a



18b



18c




NOTE:

SIDE VIEW

The clamp must have full contact along its face.




Clamp



Vehicle




Clamp






Vehicle


19 Repeat step **18** for Clamp **S**, **R** and **P** in that order



20 On **RL** clamp **Q**, tighten the bolts using the torque tool **I** + **V**, until it clicks signifying they are torqued to spec.




21 Repeat step **20** for Clamp **S**, **R** and **P** in that order.




22



Close doors **carefully** to confirm all clamps clear the doors




23



REPEAT FOR ALL 4 CLAMPS




24



NOTES

NOTES



RHINO-RACK®

MAKE SPACE FOR ADVENTURE

RHINORACK.COM

Rhino-Rack AUSTRALIA

22A Hanson Pl,
Eastern Creek, NSW, 2766

Rhino-Rack USA

19822 E 22nd Ave,
Aurora, CO, 80011